






## Sanitary High-Lift Box/ Container Dumper

EE-1135



 Flexicon manufacturing locations  
 Flexicon factory-direct field sales  
 Flexicon manufacturers' representatives

# flexicon®

### USA

FLEXICON CORPORATION  
Tel: +1 610 814 2400  
E-mail: [sales@flexicon.com](mailto:sales@flexicon.com)  
Web: [www.flexicon.com](http://www.flexicon.com)

### UK

FLEXICON (EUROPE) LTD  
Tel: +44 1227 374710  
E-mail: [sales@flexicon.co.uk](mailto:sales@flexicon.co.uk)  
Web: [www.flexicon.co.uk](http://www.flexicon.co.uk)

### AUSTRALIA

FLEXICON CORPORATION  
(AUSTRALIA) PTY LTD  
Tel: +61 7 3879 4180  
E-mail: [sales@flexicon.com.au](mailto:sales@flexicon.com.au)  
Web: [www.flexicon.com.au](http://www.flexicon.com.au)

### SOUTH AFRICA

FLEXICON AFRICA (PTY) LTD  
Tel: +27 41 453 1871  
E-mail: [sales@flexicon.co.za](mailto:sales@flexicon.co.za)  
Web: [www.flexicon.co.za](http://www.flexicon.co.za)

### SPAIN

FLEXICON EUROPE SPAIN  
Tel: +34 930 020 509  
E-mail: [ventas@flexicon.es](mailto:ventas@flexicon.es)  
Web: [www.flexicon.es](http://www.flexicon.es)

### FRANCE

FLEXICON EUROPE SAS  
Tel: +33 7 61 36 56 12  
E-mail: [ventes@flexicon.fr](mailto:ventes@flexicon.fr)  
Web: [www.flexicon.fr](http://www.flexicon.fr)

### GERMANY

FLEXICON EUROPE GmbH  
Tel: +49 173 900 78 76  
E-mail: [vertrieb@flexiconeurope.de](mailto:vertrieb@flexiconeurope.de)  
Web: [www.flexicondeutschland.de](http://www.flexicondeutschland.de)

### SINGAPORE

FLEXICON SINGAPORE PTE LTD  
Tel: +65 6778 9225  
E-mail: [sales@flexicon.com.sg](mailto:sales@flexicon.com.sg)  
Web: [www.flexicon.com.sg](http://www.flexicon.com.sg)

### INDONESIA

FLEXICON SINGAPORE PTE LTD  
Tel: +62 81 1103 2400  
E-mail: [sales@flexicon.co.id](mailto:sales@flexicon.co.id)  
Web: [www.flexicon.co.id](http://www.flexicon.co.id)

## Sanitary High-Lift Box/ Container Dumper

This sanitary TIP-TITE® High-Lift Box/Container Dumper from Flexicon discharges dust-free into vessels 6 to 10 ft (1830 to 3050 mm) above the plant floor.

Boxes and other containers are loaded at floor level and hydraulically seated against a discharge hood. The assembly is then hydraulically elevated and tipped, causing the discharge hood spout to seat against a gasketed receiving ring installed on any receiving vessel or process equipment. Opening of a pneumatically actuated slide gate valve at the spout outlet allows controlled, dust-free discharge, while closing it allows partially empty boxes and containers to be returned to the plant floor.

The unit accommodates Gaylords and other boxes from 36 to 48 in. (915 to 1220 mm) on a side and 39 to 44 in. (990 to 1117 mm) overall height.

Constructed of stainless steel finished to food, pharmaceutical or industrial standards, the unit is engineered to perform with fail-safe reliability under constant use in demanding environments.

It is also available constructed of carbon steel, and offered with optional receiving hoppers configured with the company's mechanical or pneumatic conveyors to transport discharged material to any plant location.



*Container platform of sanitary TIP-TITE® High-Lift Box/Container Dumper raises to form dust-tight seal between container and discharge hood before the assembly is raised vertically and then tipped, mating the hood outlet with the gasketed inlet port on any receiving vessel 6 to 10 ft (1830 to 3050 mm ) high.*

# flexicon®

### USA

FLEXICON CORPORATION  
Tel: +1 610 814 2400  
E-mail: [sales@flexicon.com](mailto:sales@flexicon.com)  
Web: [www.flexicon.com](http://www.flexicon.com)